

Quattro- Step 3-4.pdf



Step 3— Make sure you place Shell A “facing sides together” with Shell B.



Step 4— Your Shell A/B layer will **NOT** lay flat on top of Shell C, and that is OK.