## Securing your Aluminum Foil- Step 2-10



Center your foil on the wrong side of BOTH of your Card Cozys (#1) (step 2). I don't think it really matters if its shiny-side down or not, but that's the way I tested it, so that's the way I've directed you. :)

The big thing here is you want to try keep your foil as smooth and wrinkle free as possible.




Stitch your foil in place to anchor it to BOTH ends of your Cord Cozy. You'll want to stitch about 1/8" from the fabric edge on both ends.



Begin folding your Card Cozy (step 3). Make sure you keep your foil pushed smoothly back up into the fold area, then press the fabric (and he foil within) while lining up your "A" notches.



Once you've aligned your "A" notches with the "B" notches (step 4), place a pin (thru ALL layers) to secure this fabric placement.



Here's how it looks on the flip side (of step 4).



Now continue your folding (step 5), keeping your foil pushed up into the fold as far as possible, and being sure your foil remains centered and smooth on the WS of your Card Cozy.

Securing your
Aluminum FoilStep 2-10
(page 2)



Here's how the flip-side of your Card Cozy looks after step 6.

This is getting a little easier now, right? :) So keep following steps thru step 10.



This is how your small Card Cozy looks when it all fold up. (after step 10).

If you're making a large Card Cozy, you'll obviously continue folding until you've created 2 more card slots.



And here's how the flip-side of the small Card Cozy should look as you move on to step 11.

:)